

## Digital LED Clock and Thermometer Instructions

To power your new LED Alarm Clock insert 3 AAA batteries or use the included USB cord to plug into any USB power source.

### Setting the Time:

1. Hold down the “mode” button until the hour numbers flash, use the “up” and “down” buttons to change the hour.
2. Tap the “mode” button to set the minutes using the “up” and “down” buttons.
3. Tap the “mode” button to change between the 12 and 24 hour (military time) format using the “up” and “down” buttons.
4. Tap the “mode” button to save the time.

### Using the Alarm:

To turn on the alarm function tap the “Alarm” button until “AL” appears above the time. The alarm sound speeds up for each minute it continues to sound. Tap the “SNZ/Light” button to snooze the alarm.

### Setting the Alarm:

1. Hold down the “alarm” button until the hour numbers flash, use the “up” and “down” buttons to change the hour.
  - a. In the 12 hour format the hour you select will determine if your alarm sounds in the AM or PM. If you want your alarm to sound in the AM only the letters “AL” for alarm should appear above the time. If you want your alarm to sound in the PM keep tapping the “up” or “down” button until “PM” appears above the time and you have reached your desired time. “AL” will also still appear in PM mode.
2. Tap the “alarm” button to set the minutes using the “up” and “down” buttons to set the minute.
3. Tap the “alarm” button to change the length of the “Snooze” function.
  - a. The “snooze” function can be set at any interval starting at five minutes and going up to 60 minutes.
4. Tap the “Alarm” button to save the alarm time.

### Using the Thermometer:

To view the temperature, tap the “Mode” button once. Tap the “down” button to toggle between Fahrenheit and Celsius. The temperature does not need to be set; it will automatically display the temperature from the surrounding area.

### Setting the Brightness:

This clock has two brightness levels. To manually change the brightness level, tap the “up” button to toggle between the high brightness and low brightness settings.

**Using Night Mode:**

Night mode will automatically dim the brightness of your clock during a set amount of time. To turn night mode on, tap the “mode” button two times until the word “off” or “on” appears on screen. Tap the “down” button to toggle between “on” and “off”.

**Setting Night Mode:**

1. Turn on night mode using instructions above.
2. Hold down “mode” button while “on” is displayed on screen until the hour numbers flash.
3. Tap the “up” and “down” buttons to change the hour you want the brightness dimming to start.
  - a. In the 12 hour format, the hour you select will determine if your brightness dims in the AM or PM. If you want your brightness to dim in the AM, then only the time will appear on screen. If you want your brightness to dim in the PM keep tapping the “up” or “down” button until “PM” appears above the time and you have reached your desired time.
4. Tap the “mode” button to set the minute, you want the brightness dimming to start, using the “up” and “down” buttons. You have successfully set the start time for Night Mode.
5. Tap the “mode” button to set the end time for Night Mode.
6. Repeat steps three and four to set the end time.
7. Tap the “mode” button to save.